


## Using the provided USB charger with your Enduro 24

Remove the battery from the Enduro 24.

Connect the USB charge lead to the battery connector. Make sure you have the correct polarity: the red wire at the battery connector should line up with the white wire with gray dashes on the coating from the charger. See photo.



Once the battery lead and charge lead are connected, plug the charger into the USB port on your computer. Or you can plug it into a power brick like those used with your smart phone.

While charging, the charger light will be red. Once the charge is complete, the light on the charger will turn off.

Unplug the charge lead from the battery. Be sure to grab it by the connectors and do not pull using the wires or you may break or damage them.